



| AFN1565 | | NOTE: When ordering spare parts. Please state the part name and part number. | | | | | |
|---------|----------|---|------|---------|----------|------------------------|------|
| Item NO | Part NO. | Part Name | Q'ty | Item NO | Part NO. | Part Name | Q'ty |
| 1 | XT10001 | Hex. Soc. Hd. Bolt | 1 | 41 | XT10039 | O-Ring | 2 |
| 2 | XT10002 | Bushing, Deflcetor | 1 | 42 | XT10040 | Plunger | 1 |
| 3 | XT10003 | O-Ring | 1 | 43 | XT10041 | Plunger Cap | 1 |
| 4 | XT10004 | Deflector, Exhaust | 1 | 44A | XT10042 | Trigger Assy.-Bump(CT) | 1 |
| 5 | XT10005 | O-Ring | 1 | | XT10077 | Trigger Assy.-Seq.(ST) | 1 |
| 6 | XT10006 | Hex.Soc.Hd.Bolt | 3 | 45 | XT10043 | Spring Pin | 2 |
| 7 | XT10007 | Cap, Machined | 1 | 46 | XT10044 | Pin Trigger | 2 |
| 8 | XT10008 | Locknut | 1 | 47 | XT10045 | Grommet | 2 |
| 9 | XT10009 | Cap Gasket | 1 | 48 | XT10046 | Guide, Contact Trip | 1 |
| 10 | XT10010 | Piston Stopper | 1 | 49 | XT10047 | Spring, Safety | 1 |
| 11 | XT10011 | Spring | 1 | 50 | XT10048 | E-ring | 1 |
| 12 | XT10012 | O-Ring | 1 | 51 | XT10049 | Adjusting Nut | 1 |
| 13 | XT10013 | O-Ring | 1 | 52 | XT10050 | O-Ring | 1 |
| 14 | XT10014 | Piston ,Head Valve | 1 | 53 | XT10051 | Adjusting Post | 1 |
| 15 | XT10015 | Seal | 1 | 54 | XT10052 | Adjusting Spring | 1 |
| 16 | XT10016 | O-Ring | 1 | 55 | XT10053 | Steel Ball | 2 |
| 17 | XT10017 | Cylinder Spacer | 1 | 56 | XT10054 | Contact Trip , Upper | 1 |
| 18 | XT10018 | O-Ring | 1 | 57 | XT10055 | Lower Safety Post | 1 |
| 19 | XT10019 | O-Ring | 1 | 58 | XT10056 | No Mar Pad | 2 |
| 20 | XT10020 | Cylinder | 1 | 59 | XT10057 | Nose | 1 |
| 21 | XT10021 | O-Ring | 1 | 60 | XT10058 | Driver Guide Cover | 1 |
| 22A | XT10022 | Driver Assembly | 1 | 61 | XT10059 | Latch | 1 |
| 23 | XT10023 | Bumper | 1 | 62 | XT10060 | Door | 1 |
| 24 | XT10024 | Driver Guide | 1 | 63 | XT10061 | Spring | 1 |
| 25A | XT10025 | Body Assembly | 1 | 64 | XT10062 | Door,Latch | 1 |
| 26 | XT10026 | End Cap, Gasket | 1 | 65 | XT10063 | O-Ring | 2 |
| 27 | XT10027 | End Cap | 1 | 66 | XT10064 | Hex.Soc.Hd.Bolt | 2 |
| 28 | XT10006 | Hex.Soc.Hd.Bolt | 3 | 67 | XT10065 | Pusher Latch | 1 |
| 29 | XT10028 | O-Ring | 1 | 68 | XT10066 | Pusher | 1 |
| 30 | XT10029 | Cover Belt Hook | 1 | 69 | XT10067 | Spring Pin | 1 |
| 31 | XT10030 | Belt Hook | 1 | 70 | XT10068 | Spring | 1 |
| 32 | XT10031 | C-Ring | 1 | 71 | XT10069 | Spiral Spring | 1 |
| 33 | XT10032 | O-Ring | 1 | 72 | XT10070 | Magazine Cover | 1 |
| 34 | XT10003 | O-Ring | 1 | 73 | XT10071 | Nail Guide Liner | 1 |
| 35 | XT10033 | Valve | 1 | 74 | XT10072 | Magazine | 1 |
| 36 | XT10034 | O-Ring | 1 | 75 | XT10073 | Nail Retainer | 1 |
| 37 | XT10035 | O-Ring | 1 | 76 | XT10074 | Hex.Soc.Hd.Bolt | 2 |
| 38 | XT10036 | O-Ring | 1 | 77 | XT10075 | Hex. Soc. Hd. Bolt | 1 |
| 39 | XT10037 | Valve Plunger | 1 | 78 | XT10076 | Locknut | 1 |
| 40 | XT10038 | Spring | 1 | | | | |