



Item	☆ Part NO.	Description	Q'ty	Item	☆ Part NO.	Description	Q'ty	Item	☆ Part NO.	Description	Q'ty
1	106227	Screw Socket Hd	4	26	100174	Roll Pin	1	51	105612	Pin	1
2	100638	Washer	4	27	100039	Roll Pin	3	52	105717	Pin	1
3	105443	Cylinder Cap Unit	1	28	105469	Trigger Valve Unit	1	53	☆ 105627	Pusher Spring	2
4	☆ 105445	Seal, Cylinder Cap	1	29	105471	Compression Spring	1	54	104044	Pin	1
5	105446	Spacer, Piston Stop	1	30	105470	Valve Stem	1	55	105613	Pusher	1
6	☆ 105447	Piston Stop	1	31	105856	O-Ring	1	56	105618	Steel Channel	1
7	103575	Spring	1	32	105473	Valve Body	1	57	106509	Pin	1
8	☆ 105449	O-Ring	1	33	105474	Trigger Unit (CT)	1	58	105604	Magazine Core Assembly	1
9	105451	Head Valve Piston	1	34	105482	Arm Guide	1	59	100654	Lock Nut	2
10	☆ 105450	O-Ring	2	35	105544	Screw Socket Hd	1	60	106858	Screw Socket Hd	2
11	105454	O-Ring	1	36	106850	Compression Spring	1	61	106400	Spring Stopper	1
12	☆ 103563	Piston Ring	1	37	105594	Nose	1	62	105616	Magazine Cap	1
13	☆ 105619	Main Piston Unit	1	38	105534	Step Pin	1	63	105617	Stopper	1
14	105456	Cylinder Seal	1	39	105598	Nose Guide	1	64	100687	Spring Washer	2
15	105610	Cylinder	1	40	109127	E-Retainer Ring	1	65	100778	Hex.Soc.Hd.Bolt	2
16	105458	O-Ring	1	41	106401	Lower Contact Arm	1	66	105600	Contact Arm	1
17	105459	Cylinder Ring	1	42	100933	Screw Socket Hd	2	67	100301	Screw Socket Hd M5*10	2
18	103738	O-Ring	1	43	105531	Nose Plate Lock	1	68	105608	Magazine Bracket	1
19	105460	O-Ring	1	44	105596	Cover, Contact Arm	1	69	101688	Screw Socket Hd	1
20	☆ 105461	Bumper	1	45	106097	Roll Pin	1	70	105715	Screw Socket Hd	2
21	☆ 105611	Driver Guide	1	46	105606	Cover, Magazine	1	71	105614	No-Mar Tip	2
22	105463	Frame	1	47	105624	Spring Pin	2	72	106726	Magazine Kit Assembly	(1)
23	105468	Seal, End Cap	1	48	105622	Spring	1	73	105477	Trigger Unit (ST)	(1)
24	105466	End Cap	1	49	106201	Bushing	1	74	106727	O-Ring Kit	(1)
25	105113	Hex.Soc.Hd.Bolt M4*18	3	50	105615	Toggle, Magazine	1				

