



NOTE : When ordering spare parts.Please state the part name and part number. ☆ : Suggested wearing parts.

Item	☆	Part NO.	Description	Q'ty	Item	☆	Part NO.	Description	Q'ty	Item	☆	Part NO.	Description	Q'ty
1		106227	Screw Socket Hd M5*30	4	22		105463	Frame	1	43		105519	Pusher Spring Lockout	1
2		100638	Washer	4	23		105468	Seal, End Cap	1	44	☆	105510	Pusher Spring	2
3		105443	Cylinder Cap Unit	1	24		105466	End Cap	1	45		105513	Pusher Spring Holder	1
4		105445	Seal, Cylinder Cap	1	25		105113	Hex.Soc.Hd.Bolt M4*18	3	46		105512	Pusher Spring Shaft	2
5		105446	Spacer, Piston Stop	1	26		100174	Roll Pin	1	47		101688	Screw Socket Hd	1
6	☆	105447	Piston Stop	1	27		100039	Roll Pin	3	48		100301	Screw Socket Hd M5*10	1
7		103575	Spring	1	28		105469	Trigger Valve Unit	1	49		105516	Magazine Bracket	1
8	☆	105449	O-Ring	1	29		105471	Compression Spring	1	50		105503	Magazine Cover	1
9		105451	Head Valve Piston	1	30		105470	Valve Stem	1	51		105509	Pin	1
10	☆	105450	O-Ring	2	31		105856	O-Ring	1	52		105502	Magazine Core Assembly	1
11		105454	O-Ring	1	32		105473	Valve Body	1	53		105544	Screw Socket Hd	2
12	☆	103542	Piston Ring	1	33		105474	Trigger Unit (CT)	1	54		105511	Magazine Latch Spring	1
13	☆	105507	Main Piston Unit	1	34		105482	Arm Guide	1	55		105567	E-Ring	1
14		105456	Cylinder Seal	1	35		105496	Driver Tip Guide	1	56		105517	Magazine Latch	1
15		105457	Cylinder	1	36		105491	Nose	1	57		105518	Bushing, Magazine Latch Spring	1
16		105458	O-Ring	1	37		105565	Cover, Contact Arm	1	58		105566	Step Pin	1
17		105459	Cylinder Ring	1	38		100933	Screw Socket Hd	2	59		105514	Magazine Cap	1
18		103738	O-Ring	1	39		100530	Screw Socket Hd	2	60		106755	Magazine Kit Assembly	(1)
19		105460	O-Ring	1	40		105568	Spring, Contact Arm	1	61		105477	Trigger Unit (ST)	(1)
20	☆	105461	Bumper	1	41		105495	Contact Arm	1	62		106727	O-Ring Kit	(1)
21	☆	105505	Driver Guide	1	42	☆	105506	Pusher	1					

