


# DIRECT DRIVE SCREWDRIVER



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	XS10041	MOTOR HOUSING	21	XS10050	MOTOR GASKET
2	XS10002	SPRING PIN	22	XS10051	INTERNAL GEAR (2)
3	XS10003	AIR INLET	23	XS10052	PLANET GEAR (6)
4	XS10004	TRIGGER	24	XS10054	PIN(6)
5	XS10005	VALVE STEM	25	XS10055	BUSHING(6)
6	XS10006	REVERSE BUSHING	26	XS10057	WORK SPINDLE
7	XS10009	O-RING	27	XS10058	CENTER GEAR
8	XS10008	VALVE SPRING	28	XS10059	REDUCTION SPINDLE
9	XS10042	CLAMP NUT	29	XS10060	BALL BEARING (2)
10	XS10010	REVERSE LEVER	30	XS10038	DECORATION RING
11	XS10043	EXHAUST DIFFUSER	31	XS10061	WASHER
12	XS10007	O-RING	32	XS10062	SCREW(2)
13	XS10013	BALL BEARING (2)	33	XS10063	QUICK CHANGE CHUCK (1/4")
14	XS10044	END PLATE(2)	34	XS10064	SET SCREW (2)
15	XS10045	ROTOR	35	XS10065	HANDLE
16	XS10016	ROTOR BLADES(5)	36	XS10066	RETAINER
17	XS10046	PIN	37	XS10067	O-RING
18	XS10047	CYLINDER	38	XS10039	IRON SHEET
19	XS10048	FRONT END PLATE	39	XS10040	DAMPING MATERIAL
20	XS10049	PINION GEAR			