



PN90-PAL.B01 A 2019/05/08

PN90-PAL		NOTE: When ordering spare parts. Please state the part name and part number.					
Item	Part NO.	Description	Q'ty	Item	Part NO.	Description	Q'ty
1	100009	Screw, Flat Hd, M8 X 25	1	52	100205	Stop, Feed Piston	1
2	107014	Exhaust Cover Holder	1	53	100207	Spring Collar	1
3	104075	Exhaust Cover	1	54	100104	C-Ring	1
4	100013	Exhaust Filter	1	55	107041	Plain Washer	4
5	107009	Cylinder Cap Unit	1	MOQ for items in the following categories is 10pcs, order quantities under 10pcs for these items will be adjusted accordingly			
6	100208	Screw Socket Hd M6*35	4				
7	103443	Seal, Cylinder Cap	1				
8	101332	Spacer Exhaust	1				
9	107016	Feed Piston Stop	1				
10	101312	O-Ring	1	1. Orings – not included in the oring kits			
11	101311	O-Ring	1	2. Screws, bolts			
12	101306	Spring	1	3. Pins - roll pin, solid pins			
13	107012	Head Valve Piston	1	4. Standard washers – not special washers.			
14	107160	O-Ring	1	5. Nuts			
15	107010	Main Piston Unit	1				
16	101316	Cylinder Seal	1				
17	107008	Cylinder	1				
18	101320	O-Ring	1				
19	101319	O-Ring	1				
20	101318	Cylinder Ring	1				
21	101322	Check Valve	1				
22	101323	Bumper	1				
23	107007	Frame Unit	1				
24	100966	Spring Pin	2				
25	100280	Trigger Valve Unit	1				
26	100327	O-Ring	1				
27	101872	End Cap	1				
28	101354	O-Ring	1				
29	107025	High Flow Driver Guide	1				
30	100332	O-Ring	1				
31	107001	Nose	1				
32	100925	Screw Socket Hd M8*28	4				
33	100349	Door Latch	1				
34	101377	Spring, Door Latch	1				
35	100078	Rubber Washer	2				
36	100347	Step Pin	1				
37	101375	Door	1				
38	101362	Pin	1				
39	101383	Pin	1				
40	103276	Rubber Washer	2				
41	100085	Spring, Check Pawl	2				
42	101381	Check Pawl Stop	2				
43	101365	Feed Pawl	1				
44	100340	Step Pin	1				
45	100336	Spring, Feed Pawl A	1				
46	100337	Spring, Feed Pawl B	1				
47	100011	O-Ring	1				
48	100098	O-Ring	1				
49	101369	Feed Piston	1				
50	100206	Spring, Feed Piston	1				
51	100342	Spring, Feed Piston	1				

PN90-PAL.B01A

Ver : PN90PAL.010A