



ECAR-D(S).B01 爆炸圖 A 2019/06/18

ECAR		NOTE: When ordering spare parts. Please state the part name and part number.											
Item	Part NO.	Description	Q'ty	Item	Part NO.	Description	Q'ty	Item	Part NO.	Description	Q'ty		
1	104362	Valve Plug	1	33	104401	Trigger Guard	1						
2	101856	O-Ring	1	34	100530	Screw M5 x 20	2						
3	104358	Compression Spring	1	35	104400	Assy-Trigger Guard	1						
4	104363	Nut	1	36	104345	Magazine Cover	1						
5	100426	Washer	2	37	104344	Pusher	1						
6	104388	Seal-Valve Stem	1	38	100777	Pusher Spring	2						
7	104364	Valve Stem	1	39	104354	Pin-Spring	1						
8	104359	Muffler	1	40	104360	Wear Plate	1						
9	104340	Insert	2	41	104347	Magazine	1						
10	100765	Spring Pin	1	42	104357	Spring-Cover Detent	1						
11	104338	Valve Housing Assy	1	43	104356	Spring-Cover Detent	1						
12	104390	O-Ring	1	44	104355	Spring Pin	1						
13	104389	Bumper Supporter	1	45	104352	Headless Screw	1						
14	104369	Return Bumper	1	46	100571	Anchor Block Lock Nut	1						
15	104392	Cylinder Sleeve	1	47	104480	Exhaust Cover	1						
16	104394	Cylinder Assembly	1	48	104361	Wear Plate	1						
17	104406	O-Ring	1	MOQ for items in the following categories is 10pcs, order quantities under 10pcs for these items will be adjusted accordingly									
18	104391	Upper Piston	1										
19	104396	Driver Pin	1										
20	104397	O-Ring	1										
21	104341	Driver	1										
22	104402	O-Ring	1	1. Orings – not included in the oring kits									
23	104393	Lower Piston	1	2. Screws, bolts									
24	104367	Plug- Piston	1	3. Pins - roll pin, solid pins									
25	104395	Grip	1	4. Standard washers – not special washers.									
26	104398	Bridge	1	5. Nuts									
27	104368	Bumper-Drive	1										
28	104346	Bumper Plate	1										
29	104371	Nose Assembly	1										
30	100933	Screw M5 x 25	5										
31	104339	Handle-Trigger Guard	1										
32	104343	Trigger-AR (LONG)	1										