

MODEL NO. : 1013J/1013JA 、 1013F/1013FA 、 SENCOG/SENCOGA

No.	Part NO.	Name	PCS	No.	Part NO.	Name	PCS
1	52010	Hammer Cap Hammer	1		13140	Nose (1013J)	1
2	90087	O-Ring	1	27	14140	Nose (1013F)	1
3	90000	O-Ring	1		38140	Nose (SENCOG)	1
4	90001	O-Ring	1	28	13150	Nose Plate	1
	13023	Piston Ram Assembly (1013J)	1		18150	Nose Plate	1
5	14020	Piston Ram Assembly (1013F)	1		13160	Magazine (1013J)	1
	38020	Piston Ram Assembly (SENCOG)	1	29	14160	Magazine (1013F)	1
6	90000	O-Ring	1		17160	Magazine (SENCOG)	1
7	90015	O-Ring (Auto Series Only)	1	30	93002	Hex. Soc. FT HD Screw (1013J 、 1013F)	1
8	18030	Cylinder	1		93001	Hex. Soc. FT HD Screw (SENCOG)	1
	18040	Cylinder	1	31	98019	Hex. Soc. FT HD Screw	2
9	18050	Bumper	1	32	18214	Magazine Retainer	1
10	18060-1	Trigger Valve Set	1	33	18170	Pusher Spring	1
11	18071	Trigger Valve Spring	1		13180	Magazine Cover (1013J)	1
12	90055	O-Ring	1	34	14180	Magazine Cover (1013F)	1
	18080	Trigger Valve	1		17180	Magazine Cover (SENCOG)	1
13	18090	Trigger Valve (Auto Series)	1		13190	Pusher (1013J)	1
	90005	O-Ring	1	35	14190	Pusher (1013F)	1
	90006	O-Ring (Trigger Valve/Auto)	1		17190	Pusher (SENCOG)	1
14	90007	O-Ring	1	36	18200	Rear Magazine Bumper	1
	90008	O-Ring (Trigger Valve/Auto)	1	37	18322-1	Automatic adjust switch kit	1
16	18310	Trigger Valve plate (Auto Series Only)	1	38	52030	Pin	1
17	90005	O-Ring (Auto Series Only)	1	39	52040	Trigger	1
18	90033	O-Ring (Auto Series Only)	1	40	18240	Seal	1
19	90009	O-Ring	1	41	20250	Pin	1
20	18100	Trigger Valve Stem	1	42	95001	E-Ring	1
	18110	Trigger Valve Stem (Auto Series)	1	43	51213	Air Silencer	1
21	90033	O-Ring (Auto Series Only)	1	44	94001-1	Air Plug	1
22	18120	Trigger Valve Guide	1	45	18282	Magazine Latch	1
22	18130	Trigger Valve Guide (Auto Series)	1	46	18273	Magazine Latch Spring	1
23	90007	O-Ring	1	47	95002	E-Ring	1
24	91013-1	Hex.HD Soc Screw + Spring Washer	2	48	92005	Washer (Not on SENCOG)	2
25	18332	Seal Retainer	1		18570	Gun Body	1
26	91001	Hex.HD Soc Screw	2	49	18590	Gun Body (Auto Series)	1

