



SCN65B-CM		NOTE: When ordering spare parts. Please state the part name and part number.									
Item	Part NO.	Description	Q'ty	Item	Part NO.	Description	Q'ty	Item	Part NO.	Description	Q'ty
1	104771	Screw M5 X 16	1	50	100077	Screw M6 X 22	4	100	106812	Magazine Post	1
2	104770	Bushing	1	51	101543	Spring	1	101	106814	Compression Spring	1
3	104075	Exhaust Cover	1	52	101018	Nut M6	1	102	106810	Magazine Cover	1
4	100933	Screw M5 X 25	4	*53	101554	Contact bolt	1	103	101855	Spring Washer	4
5	101498	Protector	2	54	101555	O-Ring	1	104	103092	Pu Spacer	1
6	100927	Rubber Protector	2	55	101557	Contact Arm	1	105	103222	Spring	1
7	105292	Cylinder Cap Unit	1	56	101482	E-Ring	1	106	101530	Spring	1
8	101505	Seal, Cylinder Cap	1	57	101558	Front Contact Arm	1	107	101529	Spring	1
9	101500	Seal Plate	1	58	101575	Contact Arm Bushing	1	108	101527	Position Block	1
10	101499	Spring	1	59	101559	Front Contact Arm Unit		109	103221	Contact Arm	1
11	100535	O-Ring	1	60	101568	No-mar pad	2	110	101649	Trigger Assembly	(1)
12	101502	O-Ring	1	*61	100080	Hook, Dust Cover	2	MOQ for items in the following categories is 10pcs, order quantities under 10pcs for these items will be			
13	101647	Head Valve Piston Unit		62	101567	Dust Cover	1				
14	101501	Head Valve Piston	1	*63	100349	Door Latch	1				
15	101504	O-Ring	1	*64	100347	Step Pin	1				
16	101503	O-Ring	1	*65	100078	Rubber Washer	4				
17	103129	O-Ring	1	*66	101560	Door	1	1.	Orings – not included in the oring kits		
18	103127	Cylinder Ring	1	*67	101553	Step Pin	2	2.	Screws, bolts		
19	103128	O-Ring	1	*68	101551	Check Pawl	1	3.	Pins - roll pin, solid pins		
20	101576	O-Ring	1	*69	101552	Spring	1	4.	Standard washers – not special washers.		
21	101506	Main Piston Unit		*70	103276	Rubber Washer	2	5.	Nuts		
21.1	101507	Main Piston	1	*71	100350	Spring, Door Latch	1				
21.2	101508	Driver	1	*72	101537	Step Pin	1				
22	101511	Cylinder	1	*73	101539	Check Pawl	2				
23	101513	Check Valve	1	*74	101541	Feed Pawl	1				
24	101514	Bumper	1	*75	101540	Spring	1				
25	101723	Frame	1	*76	101538	Step Pin	1				
26	101520	Spring	1	*77	100336	Spring	1				
27	101519	Trigger lock dial	1	*78	100337	Spring	1				
28	101521	Trigger lock lever	1	*79	101544	Step Pin	1				
29	100174	Roll Pin	2	*80	100872	O-Ring	1				
30	100966	Roll Pin	2	*81	100642	O-Ring	1				
31	100045	Screw M6 X 40	1	*82	101545	Feed Piston	1				
32	100046	Washer	1	*83	101547	Spring	1				
33	100117	Nut, Elastic Stop M6	2	*84	101546	Spring	1				
34	100040	O-Ring	1	*85	101548	Feed Piston Stop	1				
35	101561	End Cap	1	*86	101549	Spring Collar	1				
36	101569	O-Ring	1	*87	101550	C-Ring	1				
37	101573	Spacer	1	88	100127	Screw M6 X 30	1				
38	101570	Hook	1	89	101562	Contact Arm Cover	1				
39	101571	Washer	1	90	100683	Bushing	1				
40	101572	C-Ring	1	91	101651	Contact Arm Cover Unit	1				
41	103223	Trigger Valve Unit	1	92	106809	Magazine	1				
*42	103243	Trigger Assembly	1	93	106078	O-Ring	2				
*44	103219	Arm guide	1	94	106816	Pin	2				
*45	101531	Adjust dial	1	95	106813	Holder Cap	1				
46	101512	O-Ring	1	96	106119	Pin	1				
47	101532	Adjust Spacer	1	97	106811	Nail Support	1				
48	100484	O-Ring	1	98	106815	C-Ring	1				
49	101535	Nose	1	99	106151	O-Ring	1				